

INSTRUCTIONS FOR USE

1. Assess the spilt liquid and review its Safety Data Sheet (SDS) before applying any absorbent. This assists in ensuring all appropriate safety precautions are adhered to, including the use of suitable PPE equipment.
2. Create a barrier around the spill using Hydrocarbon Containment Booms or Containment Socks
3. Place Hydrocarbon Pillows under any continuing leaks
4. Cover the spilt liquid with Absorbent White Hydrocarbon pads
5. Use Hydrocarbon Containment Booms or Containment Socks to 'drag' the spill across the water, containing the spill within the smallest possible area
6. Remove the Hydrocarbon soaked pads from the water surface and apply more, if required. Wipe clean any areas or equipment not cleaned
7. Place all saturated absorbent products in the waste disposal bag provided and dispose of in accordance with local government regulations
8. Complete an incident report
9. Complete an inventory then replace all used spill kit items

CONTENTS

ES-PWB-240-R	240L Red Wheelie Bin	1
ES-PP-400-P	SpillSmart Poly Pads Oil Only - 48cm x 43cm Heavy Weight - Dimpled & Perforated	100
ES-SPAO-75-1.2	SpillSmart Poly Absorbent Socks – Oil Only – 75mm x 1.2m	5
ES-PBSS-125-3	SpillSmart Poly Booms – Single Skinned with clips 125mm x 3m	2
ES-P-POLY	SpillSmart Oil Only Poly Pillow 45cm x 45cm	1
ES-G-NL	Pair of Nitrile Gloves	2
ES-WB	SpillSmart Contaminated Waste Bags - 450mm x 720mm	10
ES-ST-OF	Spill Kit Sticker	1
ES-SKIN	Spill Kit Instructions	1