

INSTRUCTIONS FOR USE

1. Assess the spilt liquid and review its Safety Data Sheet (SDS) before applying any absorbent. This assists in ensuring all appropriate safety precautions are adhered to, including the use of suitable PPE equipment.
2. Contain the spill using the absorbent or containment sock.
3. Apply absorbent to cover spill.
4. The mix of absorbent and the spill should appear dry, if not, apply more absorbent until it looks dry.
5. Using a stiff broom, sweep absorbent over the spill area.
6. If the mix does not appear dry or there remains an oily film on the surface, apply additional absorbent.
7. Use pads to wipe clean any area or equipment not cleaned by the absorbent.
8. Dispose of in accordance with local government regulations.
9. Complete an incident report and file.
10. Re-stock kit with replacement stock.

CONTENTS

ES-PWB-120-R	120L Red Wheelie Bin	1
ES-PP-400-P	SpillSmart Poly Pad - Oil Only - 48cm x 43cm x Heavy Weight (approx 400gsm) - Dimpled & Perforated	25
ES-A-FS-10	SpillSmart FloorSweep 10kg	2
ES-SPAO-75-1.2	SpillSmart Poly Absorbent Socks - Oil Only - 75mm x 1.2m	3
ES-SPAO-75-3	SpillSmart Poly Absorbent Socks - Oil Only - 75mm x 3m	1
ES-P-POLY	SpillSmart Oil Only Poly Pillows - 45cm x 45cm	1
ES-G-NL	Pair of Nitrile Gloves	2
ES-WB	Contaminated Waste Disposal Bag - 450mm x 720mm	7
ES-DPB	Dust Pan & Brush	1
ES-ST-OF	Spill Kit Sticker	1
ES-SKIN	Spill Kit Instructions	1