

INSTRUCTIONS FOR USE

1. Assess the liquid that was spilled before applying any of the Spill Kit products. Consult the products SDS to assist in ensuring that all appropriate safety precautions are taken.
2. Protect yourself and wear correct PPE.
3. Stop the Spill at the Source.
4. Contain the Spill using the white containment socks. The white Pillow can also be put underneath a leak. **Pillow supplied in 50L Oil & Fuel (Hydrocarbon) Spill Kits and above.*
5. Use the White Pads to absorb liquid, a final clean and / or a tool and equipment wipe down.
6. Dispose of in accordance with local government regulations
7. Complete an incident report and file.
8. Re-stock the spill kit with replacement stock.

CONTENTS

ES-PAAB-W15	15L Plastic Spill Kit Bag	1
ES-PP-400-P	SpillSmart Poly Pad - Oil Only - 48cm x 43cm x Heavy Weight - Dimpled & Perforated	10
ES-SPAO-75-1.2	SpillSmart Poly Absorbent Socks - Oil Only - 75mm x 1.2m	1
ES-G-NL	Pair of Nitrile Gloves	1
	Cable Tie	1
ES-ST-OF	Spill Kit Sticker	1
ES-SKIN	Spill Kit Instructions	1