

INSTRUCTIONS FOR USE

1. Assess the spilt liquid and review its Safety Data Sheet (SDS) before applying any absorbent. This assists in ensuring all appropriate safety precautions are adhered to, including the use of suitable PPE equipment.
2. Create a barrier around the spill using Hazchem Containment Booms or Containment Socks
3. Place Hazchem Pillows under any continuing leaks
4. Cover the spill with the loose HazSorb absorbent
5. Using a stiff broom, sweep the loose absorbent over the spill area
6. If there still appears to be free liquid visible (if the spilt liquid and absorbent mix does not appear dry) or if there remains an oily film on the surface, apply additional loose HazSorb absorbent
7. Use Hazchem pads to wipe clean any area or equipment not cleaned by the loose absorbent
8. Place all saturated absorbent products in the waste disposal bags provided and dispose of in accordance with local government regulations
9. Complete an incident report
10. Complete an inventory then replace all used spill kit items

CONTENTS	ES-SKB-80B	80L Blue PVC Spill Kit Bag	1
	ES-PPHAZ-400-P	SpillSmart Poly Pads HazChem - 48cm x 43cm x Heavy Weight - Dimpled & Perforated	20
	ES-A-HAZ-35	SpillSmart HazSorb 30L bag	1
	ES-SPHZ-75-1.2	SpillSmart Poly Absorbent Socks – Hazchem – 75mm x 1.2m	2
	ES-P-HAZ-A	SpillSmart Poly Hazchem Pillows – 45cm x 45cm	1
	ES-G-NL	Pair of Nitrile Gloves	1
	ES-WB	SpillSmart Contaminated Waste Bags - 450mm x 720mm	3
	ES-DPB	Dust Pan & Brush	1
	ES-ST-HAZ	Spill Kit Sticker	1
	ES-SKIN	Spill Kit Instructions	1